










TYPE: Landcruiser 80 Series
MODEL: FJ80, FZJ80, HZJ80
YEAR: 08/1991 - 1998
DETAIL: Station Wagon

FRONT		QTY	PART NUMBER	PRICE	REAR		QTY	PART NUMBER	PRICE
COIL SPRINGS					COIL SPRINGS				
	Variable Rate Standard Height	1	C59-210V	B		Variable Rate Standard Height	1	C59-221V	B
	Variable Rate Raised Height (40mm Lift) Up to 50Kg Accessories (Bullbar OR Winch)	1	C59-220V	B		Variable Rate Raised Height (45mm Lift) Comfort Spring - Petrol Only No Load	1	C59-269V	B
	Variable Rate Raised Height (40mm Lift) 50-100Kg Accessories (Bullbar AND Winch)	1	C59-222V	B		Linear Rate Standard Height	1	C59-243	B
	Linear Rate Standard Height	1	C59-174	B		Linear Rate Raised Height (45mm Lift) Up to 100Kg Constant Load (Recommended)	1	C59-169	B
	Linear Rate Raised Height (45mm Lift) Up to 50Kg Accessories (Bullbar OR Winch) (Recommended)	1	C59-168	B		Linear Rate Raised Height (60mm Lift) Up to 100Kg Constant Load	1	C59-167	B
	Linear Rate Raised Height (45mm Lift) Up to 100Kg Accessories	1	C59-166	B		Variable Rate Raised Height (45mm Lift) Up to 100Kg Constant Load	1	C59-223V	B
	Linear Rate Raised Height (60mm Lift) No Accessories	1	C59-166	B		Linear Rate Raised Height (50mm Lift) 350Kg Constant Load	1	C59-171	C
SHOCK ABSORBERS					SHOCK ABSORBERS				
	Heavy Duty Twin Tube Gas	2	GS59-683			Heavy Duty Twin Tube Gas	2	GS59-682	
	Heavy Duty Monotube Remote Reservoir	2	MR59-60683			Heavy Duty Monotube Remote Reservoir	2	MR59-60682	
STEERING DAMPERS					UNDER BODY BUSH KITS				
	Heavy Duty (Big Bore) Complete with Fittings	1	SD59-824		Kit Includes Front & Rear Under Body Bushes				
UNDER BODY BUSH KITS					2 x Front Radius Rod to Chassis Bush 4 x Front Leading Arm Bush 2 x Front Panhard Rod Bush 4 x Rear Upper Trailing Arm Bush 4 x Rear Lower Trailing Arm Bush 2 x Rear Panhard Rod Bush				
See Rear Under Body Bush Kit					1 PB59-1258K				
CASTOR ADJUSTMENT PARTS					BRAKE ADJUSTERS				
Adjustable Front Radius Arm Castor Kit Angle Settings: $\pm 0^\circ$ or $\pm 2.5^\circ$ 4 x Polyurethane Eccentric Bushes					Recommended when Raising Vehicle				
1 PB59-503K					1 BA45-005				
Fixed Rubber Front Radius Arm Castor Kit Angle Setting: $\pm 2.5^\circ$ 4 x Rubber Eccentric Bushes									
1 RB59-522K									
Raising Vehicle Will Effect Castor Angle. A Wheel Alignment is Recommended to Determine if a Castor Kit is Required.									
RADIUS ARM BUSHES									
0 Degree Standard Radius Arm Bush Kit Arm to Diff 4 x Rubber Bushes									
1 RB59-536K									
Arm to Chassis Bush Kit 2 x Rubber Bushes									
1 RB59-534K									